





PIPE TOOLS & VISES  
SINCE 1896

# Aluminum Strap Wrench Operating Instructions



Position for gripping thin walled tubing.



Position for gripping heavy walled tubing.

The picture above — along with the directions below — explain how to operate the Strap Wrench for turning in a clockwise rotation. For counterclockwise operation, simply reverse the handle 180°.

Thread the strap as pictured above with the item you wish to turn in the area marked “A.” Adjust the strap until the item to be turned rests 1/4” to 1/2” below the curved portion of the handle, as marked by “B.” Turn the handle in the clockwise direction. It should not be necessary to hold the strap when it is positioned correctly in the handle. Readjust for a new bite when necessary.

| Catalog Number | Item Code | Pipe Capacity |             | Tube Capacity |             |
|----------------|-----------|---------------|-------------|---------------|-------------|
|                |           | Inches- Nom   | Actual Ø mm | Actual Inches | Actual Ø mm |
| ASW12A         | 02231     | 1/8 - 2       | 10 - 63     | 3 1/2         | 90          |
| ASW12A30       | 02232     | 1/8 - 5       | 10 - 127    | 7 1/2         | 190         |
| ASW18A         | 02233     | 1 - 5         | 33 - 127    | 6             | 150         |
| ASW18A48*      | 02234     | 1 - 12        | 33 - 305    | 12            | 300         |
| ASW24A         | 02235     | 2 - 12        | 60 - 324    | 14            | 350         |

**\*Caution: Do not use this wrench beyond its pipe or tube capacity.**

Reed Manufacturing Company  
1425 West 8th Street  
Erie, PA 16502 USA




Phone: 800-666-3691 or 814-452-3691  
Fax: 800-456-1697 or 814-455-1697  
www.reedmfgco.com

1117-52239




PIPE TOOLS & VISES  
SINCE 1896

# Aluminum Strap Wrench Operating Instructions



Position for gripping thin walled tubing.



Position for gripping heavy walled tubing.

The picture above — along with the directions below — explain how to operate the Strap Wrench for turning in a clockwise rotation. For counterclockwise operation, simply reverse the handle 180°.

Thread the strap as pictured above with the item you wish to turn in the area marked “A.” Adjust the strap until the item to be turned rests 1/4” to 1/2” below the curved portion of the handle, as marked by “B.” Turn the handle in the clockwise direction. It should not be necessary to hold the strap when it is positioned correctly in the handle. Readjust for a new bite when necessary.

| Catalog Number | Item Code | Pipe Capacity |             | Tube Capacity |             |
|----------------|-----------|---------------|-------------|---------------|-------------|
|                |           | Inches- Nom   | Actual Ø mm | Actual Inches | Actual Ø mm |
| ASW12A         | 02231     | 1/8 - 2       | 10 - 63     | 3 1/2         | 90          |
| ASW12A30       | 02232     | 1/8 - 5       | 10 - 127    | 7 1/2         | 190         |
| ASW18A         | 02233     | 1 - 5         | 33 - 127    | 6             | 150         |
| ASW18A48*      | 02234     | 1 - 12        | 33 - 305    | 12            | 300         |
| ASW24A         | 02235     | 2 - 12        | 60 - 324    | 14            | 350         |

**\*Caution: Do not use this wrench beyond its pipe or tube capacity.**

Reed Manufacturing Company  
1425 West 8th Street  
Erie, PA 16502 USA



Phone: 800-666-3691 or 814-452-3691  
Fax: 800-456-1697 or 814-455-1697  
www.reedmfgco.com

1117-52239